



# **PROCONTROL**<sup>®</sup>



RFID Proximity card reader

# User's guide



November, 2015



Procontrol Electronics Ltd.



#### © 2015 Procontrol Electronics Ltd.

All rights reserved.

The KeySafe<sup>®</sup> ProxerGate<sup>®</sup>, ProxerPort<sup>®</sup>, IP Thermo<sup>®</sup>, IP Stecker<sup>®</sup>, ProxerLock<sup>®</sup>, ProxerStecker<sup>®</sup>, RHS<sup>®</sup>, HI-CALL<sup>®</sup>, HI-GUARD<sup>®</sup>, MEDI-CALL<sup>®</sup>, Pani-Call<sup>®</sup>, PROXER<sup>®</sup>, PROXERNET<sup>®</sup> are official brand names of Procontrol Electronics Ltd.

Trademarks in the document are property of the respective owners. Procontrol Electronics Ltd. reserves all copyright for the document: it may not be copied for third party, modified and published without prior written permission of the author.

Procontrol Electronics Ltd. reserves the right to alter the document and the software without notice.

Procontrol Electronics Ltd. assumes no liability for the accuracy of the product, the software parts and documentation and also for its adequacy and usability for specific applications.





Procontrol Electronics Ltd.

www.procontrol.hu



# Contents

Welcome	5
Security guide	6
General description	7
Features:	7
Parameters, customization	7
Package contains	7
Option:	7
Types	9
All the Proxer7 type is available in external design.	9
Explanation of the type designation	
Communication interface and output	
RFID interface attributes	
Detailed description	
Available versions	
Adjustable parameters overview	
All-type parameters	
Only for types with two way communication	
Only for types with RS232 and RS45	
Only for types with USB	
Parameters description	
Card present function	
Adjustable sound- and light signals	
Sent bit number	
Sent datatype	
Sent number of characters	
Additional character	
Message template	
Enter sending	
Code into two parts	
Communication protocol	



Procontrol Electronics Ltd.



www.procontrol.hu



# Procontrol Proxer7

Commands:	19
Authority feedback	
Device modes – transmitter searching	20
Sending of the transmitter data	20
Baud-rate	21
The USB peripheral emulation types	21
Language of keyboard emulation	21
Using of the Proxer7	22
Connection to the PC	
General use of the card reader	24
Card reading in optimal distance	
Parameter restoring to the default status - RESET	24
Program loader mode	24
Installation on Windows XP	25
Settings of the serial port, control on Windows XP operating system	
The Proxer7Manager program	
Lights- and sound signals	
Basic function:	
Update in the Proxer7 device	
Technical description	
RFID Proximity compatibility, features	
Technical parameters	
Compatible operating systems	
Wiring, connection	41
Proxer7 OEM (1)	
Proxer7 OEM (2)	
Proxer7-FF-232	



Procontrol Electronics Ltd.





Welcome

Thank you for choosing a Procontrol product.

Procontrol Electronics Ltd has grown to an important national company of developing and manufacturing software, hardware, electronic devices, access control systems, work time attendance systems, queue control, client caller, and access protection systems since 1981. Thousands of satisfied customers have experienced the security ensured by our long run planning, reliable works, and the world trademarks standing behind us.

Our total product range can be viewed on our web page: www.procontrol.hu.



Procontrol Electronics Ltd.



www.procontrol.hu



Security guide

Please read this guide carefully before installing and using the device. Please use the device properly and as described in the following manual.

The guarantee is insured only if the device is used with the implements approved or specified by the manufacturer, and it is cleaned and maintained as described in this guide.

- The manufacturer does not take warranty for the faults arising from improper use.
- Incorrect installation
- Connecting to inappropriate electric network
- Incorrect maintenance
- Not approved modifications, interventions
- Using non-original spare components
- Do not store and operate the device out of the given temperature ranges, it can lead to malfunction
- Do not try to modify or dismount any part of the device
- Do not allow the indoor version types of this product to come into contact with water or other liquids.
- Do not store the device close to a heat source or direct flame
- Use the device only the proper way as described in the guide.
- Use the equipment only for the purpose it has been designed for.

#### About the security

Use the power supply provided by manufacturer for the device. Use electric power connection as specified in this guide.

#### To avoid fire and electrical shock

Be aware that nobody pushes trash, gums and other stuffs into the slots of the device. Do not install attachments and accessories that are not designed for this device. Unplug the device in case you do not use it for a very long time.

#### Cleaning

Power down the device before starting the cleaning process. Use wet cleaning rag.

#### General rights and responsibilities

Procontrol Ltd has the exclusive right for producing the device.

Procontrol Electronics Ltd. reserves the right to modify this documentation and software without notice.

In no event shall Procontrol Ltd. be liable for any claim, damages or other liability out of or in connection with the usage of the device.

Warranty period is 2 years.



Procontrol Electronics Ltd.





# **General description**

The Proxer7 is a proximity card reader, which provides RFID cards and transponders (of various shapes, such as wristbands or keyfobs) to read. The Proxer7 enables a secure and simple authentication. The communication without physical contact allows a long service life. The Proxer7 is a widely used RFID reader device, knows a wide range of communications protocols and encoder types.

### **Features:**

- RFID Proximity card reader
- Desktop version with USB or RS232
- Optional wall-mounted version with RS485 and Wiegand
- 125/134 kHz and/or 13,56 MHz
- Encoders, mobile phones with NFC module
- Size: 79 x 117 x 24 mm
- User-configurable properties
- Extensive integration
- Multicolored LED ligh



### Parameters, customization

The Proxer7 has a number of adjustable parameters. The detailed description can be found in these parts of the document:

- Optional card reader- and data transmission modes
- Card data sending to the host device
- Optional communications protocol
- Configurable entitlement feedback
- Variable light and sound signals
- Optional USB peripheral device emulation

### Package contains:

- Proxer7(USB): Proxer7 reader+USB A micro B cable
- Proxer7(RS232): Proxer7(RS232) reader
   + RS232 serial cable + power supply
- Proxer7(RS485): Proxer7(RS485) reader
   + 1m patch cable
- Documentation and installation CD, Proxer7Manager program

### **Option:**

- Power supply
- Cable, passive PoE kit









• Cross cable





PROCONTROL ELECTRONICS LTD www.procontrol.hu



8. oldal / 44



# Types

Туре	microU SB	RS232	RS485	Wiegand	Low Frequenc y reader	High Frequency reader	Outer output	Inner output	STP output
Proxer7-EM-U	$\checkmark$				Only EM		$\checkmark$		
Proxer7-LF-U	$\checkmark$				$\checkmark$		$\checkmark$		
Proxer7-HF-U	$\checkmark$					$\checkmark$	$\checkmark$		
Proxer7-FF-U	$\checkmark$				$\checkmark$		$\checkmark$		
Proxer7-EM-232					Only EM		$\checkmark$		
Proxer7-LF-232					$\checkmark$		$\checkmark$		
Proxer7-HF-232						$\checkmark$	$\checkmark$		
Proxer7-FF-232					$\checkmark$		V		
Proxer7-EM-485					Only EM				
Proxer7-LF-485					$\checkmark$				
Proxer7-HF-485						$\checkmark$			
Proxer7-FF-485					$\checkmark$	$\checkmark$			
Proxer7-EM-W					Only EM				
Proxer7-LF-W					$\checkmark$				
Proxer7-HF-W									
Proxer7-FF-W					$\checkmark$				
Proxer7-T-EM-485STP					$\checkmark$			$\checkmark$	$\checkmark$
						·			


All the Proxer7 type is available in external design.





PROCONTROL<sup>®</sup>

### Explanation of the type designation



# Communication interface and output

#### **Explanation:**

External interfaces:	Desktop application. The connector is on one of the shorter outsidevice.	des of the
Internal interfaces:	The connector is in the inside of the device. Fixed reader application mounted terminal)	ons (wall-
One-way communication:	Only for data sending.	
Two-way communication:	Data sending, receiving.	

Туре	Direction of communication	Configuration	Type of connector
U	2 Direction	Outer	micro USB-B, USB 2.0
RS232	2 Direction	Outer	9 pole D-SUB, 5,5mm DC connector socket
RS485	2 Direction	Inner	RJ45 connector







Wiegand	1 Direction	Inner	4 pole connector

# **RFID** interface attributes

Name	Operating frequency range	
Low Frequency reader	125-134kHz	
High Frequency reader	13,56MHz	



PROCONTROL ELECTRONICS LTD www.procontrol.hu



11. oldal / 44



# **Detailed description**

### Available versions

The Proxer7 Proximity RFID card reader is a desktop device designed for use in a confined space, it has no special immunity. Accordingly, the basic version available in the two most widely used office types of connections, with USB or RS232. In these versions, the connector is on the outside of the box, can be connected to a personal computer with standard external data cable.

Because nowadays widespread access control using RS485 or Wiegand communication interface, the Proxer7 is available with these versions. The Proxer7 is eligible in wall-mountable design with internal connector for the cables are inside of the housing,

The Proxer7 is basically external input peripherals, responsible for reading the RFID transponder ID and transmission via communication interface, similar to an external keyboard, which is used to input a code. In normal using the success of the communication, transmission with the RFID transponder will be showed with sound and lights signaling, the user can be sure of the reading success. The device sounds, lights and signaling capabilities can be used to further entitlement feedback too, which instructed the eligibility by the computer, in case of bidirectional communication capability interfaces.

The Proxer7 is a great configurable device that allows the use of existing ex-post, in-built system. Changing the parameters often change the basic operation of the device, which in extreme cases can result in even further communications fail. For the easier handling and restore the default settings, on the Proxer7 desktop versions back is a RESET button, by pressing restarts the device with default parameters.

### Adjustable parameters overview

To the settings you need a pc, connected reader and the Proxer7Manager program.

#### All-type parameters

Parameter name	Settings options	Explanation
Card present, transmitter	ON OFF	The device sends the data of the encoder several times continuously. Card present
watching		
Lights	Regular	Type of light signals









	Proxer6 scheme	
Tone	12 tone alarm	The signals are separately changeable
Sent bit number	Number: 1 - 64	It determines whether bit of RFID card will be transmitted.
Sent data type	Decoded card data Undecoded card data	The device will decode the RFID identifier before the sending

#### Only for types with two way communication

(With RS485, RS232 and USB cables. With Wiegand the device will not give any result.)

Parameter name	Setting options	Explanation
Sent character number	Number: 1 - 255	Determines how many characters of the RFID card code will be sent out.
Supplementary character	Optional character	If the RFID code need less character, the code will be supplemented with that character
Message templates	25 character long template	Data will be inserted between frames to the sending,
Enter sending	ON OFF	Determines, that an ENTER character will follow the sent message or not.
Code into two parts	2 * 16 bit sending 1* 32 bit sending	Determines, that the code will be sent as 1 32bit number or 2 16bit numbers.
Communication protocol	ASCII	Simple text message communication with HOST
•	PCS	PCS type communication with HOST
Authority feedback	ON OFF	The device needs a command about eligibility or not.
	Automatic	The device starts automatically transmitter searching







Transmitter searching	Command	The device needs command to the transmitter searching
Transmitter	ON	The device can send the data of the transmitter, not only the
data sending	OFF	ID number.
	OFF	

#### Only for types with RS232 and RS45

Parameter name	Setting options	Explanation	
Baud-rate         1200, 2400, 4800, 9600, 14400, 19200, 28800, 38400, 56000, 57600, 115200, 128000, 256000		The serial communication bit rate can be selected.	TR

#### Only for types with USB

Parameter name	Setting options	Explanation
USB Emulation type	Virtual serial port Virtual keyboard	The PC recognizes the card reader as a virtual serial port or a virtual keyboard.
Virtual Keyboard language	HUN ENG	The emulated USB keyboard language can be selected

### **Parameters description**

#### Card present function

The Proxer7 Proximity RFID reader is able to continual card presence observing, thereby further expanding the capabilities of the reader. For example, the RFID card can be used as hardware key, where the computer application will run only as long, as the authorized card is on the reader. The Proxer7 reader with default settings will be reading the ID transmitter only once, if the transmitter does not leave the radio frequency field. The watching of the transmitter presence is a switchable parameter, the effect depends on the







mode of searching, and it has effect only with automatic adjustment. The device in case of RFID transmitter gives sounds-, and lights signal only once, but in activated case sends constantly the ID at regular intervals (333ms) to the HOST device until the owner transmitter is in the reading field.

Condition of card present funtion	Automatic reading	Command to read
Parameter ON	At detecting a new RFID transmitter, the device gives one light signal and as long as the transmitter does not leave the reading field will be in every 250 seconds the ID to the HOST sent.	At detecting a new RFID transmitter (it begins with the command,) the device sends once a light and sound signal, until the transmitter does not leave the reading field. With the command of the HOST will be the last read ID sent.
Parameter OFF	At detecting a new RFID transmitter, the device gives one light signal and until the transmitter in the reading field, sends the ID only one time.	The device detecting for new RFID transmitter only with command. In case of new transmitter, gives one light- and sound signal, send the read ID to the HOST and then switch off the reading field.

#### Adjustable sound- and light signals

On the Proxer7 device are the sound- and light signals changeable. In case of the sound signals is there 4 versions (ON, OFF, authorized transmitter, unauthorized transmitter), all of them are adjustable parameters. To the customization are available 12 pre-defined audio samples, each of them can be selected as a sound signal. Light signals have two schemes. The "Proxer7" scheme is of the Procontrol Electronics Ltd. own developed light-signaling scheme. The description of the light signaling sees at the end of the document.

#### Sent bit number

The RFID transponder ID can be represented by number of bits. This parameter is a numeric value; the Proxer7 reader will send the data according to the number of bits. The number of bits interprets by LSB. The following table shows the effect of the parameter on the 32547698 ID. The binary is to 32 bits, the decimal data is to 10 characters supplemented to see.

Sent bit number	Got binary and decimal numbers	
32	Binary	00000001111100001010001101110010
	Decimal	00 <b>32547698</b>
20	Binary	00000000000000000001010001101110010







	Decimal	0000041842
12	Binary	000000000000000000000000000000000000000
	Decimal	0000000882

#### Sent datatype

The RFID transponders are from general to allow the verification of the correctness of the data stream in either parity bits, or using 'checksum'. The Proxer7 reader verifies the correctness of the data stream in all cases. It also happens that the transponder's physically printed ID came from the given sequence of data stream. So we talk decoded and undecoded data stream. In both cases the data stream identifies the card. The decoding is the recover to the provided number by the manufacturer, the possibility of individual identification with the transponder is not affected.

The undecoded data stream will be in all cases in hex format forward.

Sent datatype	Explanation
Decoded	If the identification of the RFID type is successful and the decoding information is available, the reader decrypts the specified identification number by manufacturer's and then transmits via communication interface to the user.
Undecoded	The RFID transponder ID will be sent to the PC 1:1, only in hex format

#### Sent number of characters

PROCONTE

The needed characters to the identification of RFID ID may be different, depending on the size of the ID number (the larger the number, the more characters can be represented only). If the connected system wait for constant number of character sending, namely does not handle the dynamically changing number of character IDs, in case of that should be send the independent of the size of ID number, which can be made with this parameter.

If the ID does not fit the here defined number of characters, the Proxer7 automatically send at the length which good for it. If the ID would be fit on shorter character, as the here defined, the Proxer7 supplement. (See under "Additional character" parameter).

If the ID does not fit the here defined number of characters, but do not want the Proxer7 send more characters because of foregoing, needed the size of ID reduce with the 'sent number of bits' parameter.





The following example illustrates the operation described above. The value of the additional characters is "0" currently. It is assumed that sending the decoded data stream is set, so the Proxer7 reader will send a decimal number.

ID	Sent number of character [parameter]	Sent number of bits [parameter]	Sent message via Proxer7
32547698	10	32	0032546798
	5	32	32546798
	5	16	41842

#### Additional character

The co-parameter of the **sent number of character** is the **additional character**. If the addition needed to the right number of character, it would be supplemented with the here defined character.

In the following example the **"sent number of character**'s value = **10**.

ID	Additional character	Sent message via Proxer7	
32547698	"0"	0032546798	
	"P"	PP32546798	

#### Message template

The Proxer7 device's basic function is the reading and sending of the RFID transponder ID. It may be necessary in established system to use a custom frames attach to the message. The Proxer7 device can store a 20 character long message, within the place of ID determined, allowing an individual parcel frame, the opening and closing characters to add to the message. The total length of the message is given here by the number of frame characters and length of ID, so the 20 character length would be not reduced.

In the following example the sent number of bits = 32, sent number of character = 10 and additional character = 0.

ID Message template		Message template	Sent message via Proxer7
	32547698	ID:[ID place]: Procontrol	ID:0032546798: Procontrol

#### **Enter sending**

If the 'ENTER sending' parameter can be sent, then fit at the end of the message an ENTER character







#### Code into two parts

A significant number of currently widespread RFID systems operate with 32-bit identifier, but the older RFID systems used 16-bit identifier. To ensure the compatibility of such systems, the user practice spread to the more advanced 32-bit identifier 2x16-bit identification number interpreted divided into two sent some readers. The, the Proxer7 can send the code into two parts with enabled parameter.

The parameter will be read with **Sent datatype** = *Decoded card data* and in case of receiving identification of appropriate length (32-bit). The parameter interacts with the **Sent characters** parameter, the number of characters will be read on the full length of message, so the 2x16-bit will be jointly represented on the character number.

The effect of the parameters showed in the following example, Sent number of bits = 32, Sent number of character = 10 and additional character = 0

ID	Code into two parts	Sent message via Proxer7
32547698	Enabled	0049641842
	OFF	0032547698

#### **Communication protocol**

The Proxer7 device knows two types of communication protocol, the ASCII protocol and the PCSW protocol developed by Procontrol Electronics Ltd. The ASCII is a simple character coder standard, based on Latin ABC. Practically service a simple text output, the ID of card will be sent as a simple numeric character string. The PCS (Procontrol Communication Standard) is the own standard of Procontrol Electronics Ltd. More complex, but more secure, packet transfer based method, the detailed description can be asked at ordering.

ATTENTION! The commands would only be executed of the correct modes and functions are activate (eligibility feedback, card presence, transmitter searching)!

The type of communication protocol is a switchable parameter. The settings vary according to the command structure; this is summarized in the table below.

Set parameters		ASCII		PCS	
		HOST command	Answer of reader	HOST command	Answer of reader
Eligibility	Automatically card reading	-	xxxxxxxxx(+Enter)		ECRRP
feedback: OFF	Manual card reading	:TRNUM?;(+Ente r)	:TRNxxxxxxx;(+Ent er)* :NO_TR;(+Enter)	CCRRE	ECRRP







Eligibility feedback: ON	:RIGHTOK;(+Ent er) :RIGHTNO;(+Ent er)	See under: Light and sound signals	EAUAC EAURE	See under: Light and sound signals.
--------------------------	--	------------------------------------	----------------	--

#### **Commands:**

ASCII protocol	
xxxxxxxxx(+Enter)	Card numbers with 10 digits accuracy, if necessary supplemented with 0, opening and closing characters. Example: 0032654396 (+Enter)
:TRNUM?;(+Enter)	To start a reading, requesting the card number.
:TRNxxxxxxx;(+Enter)	Card numbers with 10 digits accuracy, if necessary supplemented with 0, opening and closing characters.*
:NO_TR;(+Enter)	There is no transmitter within range of the reader after 2 seconds.
:RIGHTOK;(+Enter)	The card is authorized.
:RIGHTNO;(+Enter)	The card is unauthorized
PCS protocol	
ECRRPdxxxxxxxxd	Card numbers with 10 digits accuracy, with 0, opening and closing characters.*
EAUAC	"Event Authentication Accepted"
EAURE	"Event Authentication Refused".
CCRRE	"Command Card Read Request"

\* The answer depends on the "Send transmitter data" parameter.

#### Authority feedback

The Proxer7 device can be integrated in examining entitlement system, based on the HOST device itself is capable to let the user know about his authority. The eligibility feedback is a switchable parameter, after the activation the sound and light signaling will be changed.

**Eligibility feedback** 

Alerts







ON	In case of new transmitter the device indicate with a short light and tone the cognition and ID sending to the HOST. Subsequently in accordance with the command of the HOST (see under: Commands) response give sound- and light signal to show the authority.
OFF	The device does not examine eligibility, gives for each new transmitter eligible tone, light signal is according to the setting.

#### **Device modes – transmitter searching**

The Proxer7 proximity RFID reader works basically in two modes, the type of modes is a switchable parameter. In the "automatic" mode the device start the transmitter search, in "the command" mode from the HOST came command stars. The settings of mode are with effect on the speed of reading and on the radio frequency field (and the consequent uneasiness). In the automatic mode the starter of reading is the device (depends on the version) or the user. The modes and their effect see in the table below:

Start of transmitter search	Wire version
Automata reading	The device creates a constant excitation field; search a new transmitter in every 333. seconds. The IDs in the reading field will be automatic send to the HOST.
Command to reading	The device periodically switches on the reading field. The reading starts the command of HOST. During the (2 sec) reading the device read each ID in the reading then switches the field and sends the ID to the HOST.

#### Sending of the transmitter data

The Proxer7 RFID card reader identifiers in the reading field the transmitter's type and parameters. The settings are for the sending of them. This function allows the user to know not only the ID number, but also the type and bit speed. The following table indicates the effect of parameters in the different communication protocols and transmitter search mode.

Communications protocol/transmitter search mode	Sending of the card data is ON
ASCII / automatic search	EMARIN_2KBAUD_0032547698
ASCII / command to search	:TRD-EMARIN_2KBAUD_0032547698;







PCS*	ECRRPd[decoded ID on 4 bytes]d[producer code on 1
	byte]d[undecoded ID on 8 bytes]d[data speed on 1 byte]d[card type
	ID 1 byte]d

\* The PCS (Procontrol Communication Standard) is the Procontrol Electronics own protocol standard, the documentation ask at the ordering process.

#### **Baud-rate**

In case of Proxer7 with RS232 and RS485 serial port is possibility to the changing of the bit speed of the communication port. After the change of the parameter need the restart of the device.

#### The USB peripheral emulation types

The Proxer7 RFID reader can more peripheries emulate with USB port to the PC connected, it allows wide range of integration. The type of emulation parameters can be adjusted by the user. The emulated peripheral devices are as follows.

Emulated periphery via USB	Short description
Virtual serial port	The PC after the install of the right driver knows the device as a serial port. Each communication with the device is easily through a simple terminal program. Parameters of serial communication: 115200kbaud, 8bit, 1 stop bit.
Virtual keyboard*	The PC know the device as a keyboard, the data will detect as a keyboard typed characters.

\* In that mode the communication can be only one way, the device can send data to the PC, reverse communication is not possible. To restore the two ways communication see below the detailed description.

#### Language of keyboard emulation

The Proxer7 with appropriate settings is suitable for multiple language keyboard emulation. The different language manifests in the practice of the different button allocation. The button code depends on the physical location of button. The same location in two different language keyboard results the same code. The PC's operating system identifies the correct character depend on the language settings. For example: the code of "0" character is on the English and Hungarian keyboard: the code of "0" on the English keyboard is "ö" character code on the Hungarian keyboard. Selecting the appropriate language ensures that the PC interpret the characters from the Proxer7 device properly.

The select of the keyboard language obviously interpreted only in case of USB keyboard emulation application. In case of other type is ineffective.








# **Using of the Proxer7**

# Connection to the PC







### Procontrol Proxer7



Install the adequate software. If the installation of virtual serial port is done, open the Proxer7Manager.exe support program (can be find on the CD).

Note: If an error is detected on Windows 7 or newer version, run the program with administrator rights.

Approach the RFID transponder to the reader, approx. 4 cm (or closer) until the device signal has been given). The reader ready to use.



Found New Hardware Wizard

#### Welcome to the Found New Hardware Wizard

Windows will search for current and updated software by looking on your computer, on the hardware installation CD, or on the Windows Update Web site (with your permission). Read our privacy policy

Can Windows connect to Windows Update to search for software?

Yes, this time only
 Yes, now and every time I connect a device
 No, not this time

Click Next to continue.

<Back Next> Cancel









### General use of the card reader

#### Card reading in optimal distance

The RFID measurement field of Proxer7 average is 5cm from the device. The transmitter reading happens in this distance.



# Parameter restoring to the default status - RESET

In some cases needed the restoring of the default status – for example if the USB emulates not a virtual serial port and we want the parameters reset. How to restore: with a thin and sharp instruments press through the tiny holes at the back of the device the RESET button

**ATTENTION!** The button already responding to the fine push. The powerful movements may damage the device.



#### Program loader mode

The RESET button pressing and holding of the device takes in the program loader mode. About the program update is a detailed description at the end of the document.

**ATTENTION!** The button already responding to the fine push. The powerful movements may damage the device.











# Installation on Windows XP

Description of steps	Illustration
When the reader connected is, the new hardware wizard starts automatically. Click the option "No, not this time" and then click Next to continue.	Found New Hardware Wizard         Welcome to the Found New Hardware Wizard         Windows will search for current and updated software by looking on your computer, on the hardware installation CD, or on the Windows Update Web site (with your permission).         Read our privacy policy         Can Windows connect to Windows Update to search for software?         Yes, this time only         Yes, this time only         Yes, now and every time I connect a device         No, not this time         Click Next to continue.
"Install from a list or a specific location (Advanced) and click Next to continue.	< Back



PROCONTROL ELECTRONICS LTD www.procontrol.hu



25. oldal / 44





	Found New Hardware Wizard
	Please choose your search and installation options.
Click Include this location in the search. Click	Search for the best driver in these locations. Use the check boxes below to limit or expand the default search, which includes local paths and removable media. The best driver found will be installed.
Browse and locate the path of the software driver (Procontrol Virtual COM Port Driver). Click Next.	Search removable media (floppy, CD-ROM)  Include this tocation in the search: D:\ Browse
	Don't search. I will choose the driver to install. Choose this option to select the device driver from a list. Windows does not guarantee that the driver you choose will be the best match for your hardware.
	< <u>Back</u> Next> Cancel
	Új hardver varázsló
Choose the suitable one to your operating system.	Az alábbi listából válassza ki a hardvernek leginkább megfelelő leírást.
	Procontrol Virtual CDM Port
	Leírás Verzió Gyártó Hely Procontrol Virtual COM Port Ismeretlen Procontrol Electronics Ltd f:\users\sz. Procontrol Virtual COM Port Ismeretlen Procontrol Electronics Ltd f:\users\sz.
	< <u> </u>
	Az illesztőprogram nincsen digitálisan Iovábbi intormáció az illesztök aláírásának tontosságáról
	< Vissza Tovább > Mégse
	Hardvertelepítés
In the next window click "continue anyway"	A következő szoftvert telepíti ehhez a hardvereszközhöz: Procontrol Virtual COM Port
	Ez a szoftver nem ment át a Windows Logo tesztelésen, amely a Windows XP-vel való kompatibilitást vizsgálja. ( <u>Miért fontos ez a</u> <u>tesztelés?</u> )
	Ha folytatja a szoftver telepítését, veszélyeztetheti vagy megingathatja a rendszer stabilitását. A Microsoft azt ajánlja, hogy állítsa most le a telepítést, és lépjen kapcsolatba a szoftver szállítójával olyan szoftverért, amely sikeresen átment a Windows Logo tesztelésen.
	Telepítés folytatása Telepítés leállítása







At the end of the installation click "Finish". The reader ready to use.	Új hardver varázsló Új hardver - a varázsló befejezése A varázsló befejezte a szoftver telepítését az alábbi eszközhöz:
	A varázsló bezárásához kattintson a Befejezés gombra.

# Settings of the serial port, control on Windows XP operating system

Some application program can not handle a bigger sequential number port as the specific communications port, so it is possible that after the Proxer7 connecting, the installed program still does not recognize the reader. In this case may be necessary the direct modify of communications port. The following guide will help you.









Description of steps	Illustration
Start the control panel (Start menu $\rightarrow$ Control panel). Click the system icon.	Vezérlőput       Image: Solation feloret kedvercek Estadok Súgó         Fój Szerlesztés Mézet Kedvercek Estadok Súgó       Mapak       Image: Foj Mapak       Ima
In the pop-up window choose the "Hardware" tab and click "Device Manager"	Rendszer tulaj donságok       C Nárosza visszaállítása       Automatikus frissítések       Távoli használat         Átalános       Számítógépnév       Hardver       Speciális         Eszközkezelő       Bardvereszközeit. Az eszközök tulajdonságainak módosításához használja az eszközök tulajdonságai eszközök tulajdonságai eszközök tulajdonságai eszközök tulajdonságai eszközök tulajdonságai eszközök eszkök eszkök eszközök eszkök eszkök eszközök eszkök eszkök eszkök es











In the next window you can see your personal computer's hardware components.. Search the "Ports (COM and LPT)" menu, then click on the little "+" button the view the devices they connected through serial port to the pc.



Search the "Procontrol Virtual Com Port" device, and than whit right button choose the "Features" option.







### Procontrol Proxer7



In the pop-up window choose the "Port settings" tab then click "Specials"

Általános Port beállítása Illesztőp	rogram Részletek		
Bit/másodperc:	9600	~	7
		•	
Adatbitek:	8	~	
Paritás:	Nincs	~	
Stopbitek:	1	~	
Átvitelvezérlés:	Nines	~	
Speciális	Alapértelmezések	. visszaállítása	
Speciális			Mégse
Speciális			
3 speciális beállításai			Mégse
	ART szükséges)		Mégse
3 speciális beállitásai ✓ FIFO pulferek használata (16550 kompatibilis U	ART szükséges) ket adjon meg.		Mégse
3 <b>speciális beállitásaí</b> ✓ FIFO pulferek használata (16550 kompatibilis U. A kapcsolat minőségének javításához kisebb értél	ART szükséges) ket adjon meg. on ki.		Mégse

In the next window next to "COM-port number" can be chosen the suitable COMport. From then the Proxer7 available trough this connected port.





# The Proxer7Manager program

To the Proxer7 reader is a Proxer7Manager program to try the basic functions and retool some of the parameters. When the program starts automatically search for the communications port to which the Proxer7 connected.

ATTENTION! If the device is not right connected to the pc, the program does not go on.

Kommunikác	iós port választás	×
Elérhető port		
	Megszakítás, kézzel akarom megadni	

The program shows on the next window the ID of read card. There is an opportunity make a list. Click "Listáz"

	asott kártya száma
10 Számjegyű	5 Számjegyű
208201462	59126
, ▼ Listáz	, Listáz











# Lights- and sound signals

The device is suitable for basic events sign (e.g. card reading, rejection of unauthorized card, faulty operation, service mode, etc.) with LED light and sound signal. The sound signals are customizable, see below "Setting Parameters" section. If the card is continuously within the read range, re-reading give not new light or tone. Each light signals communicate with the following warning message:

# **Basic function:**

- 1. <u>Successful starting</u>: 3 short, rapid, green blink
- 2. <u>Normal operating state</u>, the reader is ready: 1 short green flash in every 10 seconds
- 3. <u>The card reader is active</u>: light green frequent blinking
- 4. Successful card readinga. <u>Eligibility without feedback</u>:
  - 1 long and 1 short green flash
  - b. Eligibility with feedback
    i. <u>Authorized cases</u>:
    - 1 long and 1 short green flash
    - ii. <u>Unauthorized cases</u>: 1 quick and 1 long red flash
- 5. Bootloader: Orange flash in every 2 seconds
- 6. Error: uninterrupted red light
- 7. <u>Knock-off</u>: 3 long, red flashes.









Case			Sound	LED-lights
Successful starting: 3 short, rapid, green blink			<b>F</b>	<b>†</b>
<u>Normal operating state</u> : the reader is ready, 1 short green flash in every 10 seconds				
The card reader is active: light green frequent blinking				10000000000000
	Eligibility without feedback	1 long and 1 short green flash	<b>₽</b>	
Successful card reading	Eligibility with	Authorized cases: 1 long and 1 short green flash	¥	
	feedback	<u>Unauthorized cases</u> : 1 quick and 1 long red flash	Ŧ	
Bootloader: Orange flash in every 2 seconds				
Error: uninterrupted red light				1
Knock-off: 3 long, red flashes.			<b>1</b>	



PROCONTROL ELECTRONICS LTD www.procontrol.hu



33. oldal / 44



# Update in the Proxer7 device

#### **Description of steps** Illustration Each device has bootloader. This is a special Procontrol FWLoader v1.8.4.139 [fell mode to new update download. Before the A kaposolat tipusa update, click FWLoader program. soros porti kapcsolat C TCP/IP (internet vagy ethernet hálózat) As the type of connection choose the "serial port connection"(soros porti kapcsolat) A használt soros port: COM 10 option, then choose the right virtual serial port(használt soros port), (connect the A soros porti baudrate: 115200 device!), baud rate option(soros porti PCS-address(A baudrate): "115200", A készülék PCS-címe: 255 \$ készülék PCS-címe): "255". Browse ? 🗙 Selected the "Firmware update" tab, load Hely: 🗀 New\_fw - 🗢 🖻 🖝 the firmware. The program is now ready to Proxer6\_20120323.pfw Ì update the current firmware. Legutóbbi dokument G Asztal Dokumentumok Sajátgép

Hálózati helyek

Fáilnév.

Fájltípus

Proxer6\_20120323

PFW állományok (\*.pfw)



PROCONTROL ELECTRONICS LTD www.procontrol.hu



Megnyitás

Mégse

-

•

# 

#### Procontrol Proxer7

Press the RESET button on the back of device until with a beep restarted. As a result, the device enters in the program loader mode, where the default parameters return (regardless of program loading).



To test the connection, click "View Unit Information" button on the device. Under the "Messages" tab then shall appear the following message:

A kiválasztott firmware tulajdonságai Kommunikációs napló Üzenetek A betöltött firmware bulldszáma: Build:00018 Készülékinformációk beolvasása... Készülékinformációk: 00018 SZABO- 2012-03-06 12:23 Projekt: 9 Készülék: 90 (készülékkód) Rx/Tx buflen: 0/0 Név: Proxer6 CardReader------ BL rev: 21 Uptime: 362 (a FW fut) The FW run Device information: 00018 SZABO- 2012-03-06 12:23 Projekt: 9 Készülék: 90 (készülékk: 90 (készülékkód) Rx/Tx buflen: 0/0 Név:

*Device information: 00018 SZABO- 2012-03-06 12:23 Projekt: 9 Keszülek: 90 (keszülekkod) Rx/1x bujien: 0/0 Nev Proxer6 CardReader----- BL rev: 21 Uptime: 921* [a FW fut] *A CPU típusa: 060 Feszültség: 000* 

The important information of this message is with red highlighted (rest of the message contains variables attached to a sample of the message). This indicates that the connection is established with the device, and this is the normal mode (not in bootloader mode).

To the bootloader mode and to the new firmware automatic install click the "Telepítés", then wait 5-10 seconds.

A kapcsolat típusa	Firmware trissitése	
C TCP/IP (internet vagy ethemet hálózat)	Válassza ki a telepítendő firmware állományát:	
	F-\Dokumentumok\Projektek\Belso\1331-11_Proxer6\Milare\New_tw\Proxer6_20120323.pfw	-
A használt soros port; COM 10	Kászülékinformációk beolvasása	PFW fájl készítése a HEX-bő
A soros porti baudrate: 115200	Leálítás 🗾 🗖 Kötegelt mód (GPRS-en gyornabb)	BIN fáj készítése a HEX-ből
A készülék PCS-címe:	A készülék árandítása 🗖 Finsítés előlt törölje a készülék, adatilest-ét	
kiválasztott firmware tulajdonságai   Kommunik.	ációs napló Üzenetek	







### Procontrol Proxer7

The firmware installing was successful.

WLoader		
A firmware	telepítése sikeresen befeje	ződött.
i i i i i i i i i i i i i i i i i i i		Louoter



PROCONTROL ELECTRONICS LTD www.procontrol.hu



36. oldal / 44



# **Technical description**

# **RFID** Proximity compatibility, features

Frequency	Card types	
Low frequency (125/134kHz)	<ul> <li>eMarine (EM4100,4102,4200)</li> <li>ProxCard II</li> <li>Indala</li> <li>Indala Kantech</li> <li>ISO 18000</li> <li>ISO 11784/85 HDX</li> <li>ISO11784/85 FDX(-B)</li> <li>TI RFID (Tiris)</li> <li>Casi Rusco</li> <li>HITAG 1/S</li> <li>HITAG 2</li> </ul>	
High frequency (13.56MHz)	• HITAG 2 ISO-14443A	
	<ul> <li>Mifare Classic (1k/4k)</li> <li>Mifare Ultralight</li> <li>Mifare DESFire</li> <li>Mifare Plus</li> <li>Mifare ProX</li> <li>Mifare SmartMX</li> <li>SLE66R35</li> </ul>	
	ISO-15693	
	<ul> <li>Texas Instruments TAG-IT Plus</li> <li>Texas Instruments TAG-IT Standard</li> <li>Texas Instruments TAG-IT Pro</li> <li>PicoPass</li> <li>HID iClass</li> <li>Legic Advant</li> </ul>	
	ISO-14443B	
	<ul> <li>SRI512, SRT512, SRI4K, SRIX4k</li> <li>ISO-14443B</li> </ul>	
	ISO-18092/NFC	
	<ul> <li>NFCIP-1</li> <li>NFC card emulation (passive)</li> <li>Mobile phone with NFC functionality (Android, iOS, Windows Mobile)with the previously mentioned modes</li> </ul>	









# **Technical parameters**

Electrical parameters					
Name of parameters	Connector type	Technical parameter			
Power supply voltage	USB	5V			
	RS232, RS485, Wiegand	12 - 24V			
Power consumption	USB	~750mW			
	RS232, RS485, Wiegand	~250mW			
Average reading distance	All-type	0 – 5cm			
Connector type	USB	microUSB AB			
	RS232	9 pole D-SUB, 5,5mm DC			
	RS485	RJ45			
	Wiegand	4pole serial terminal			
Communication standard	USB	USB 2.0			
	RS232	RS232			
	RS485	RS485			
	Wiegand	Wiegand 26 (< 37) bit			
LED indicator	All-type	1 LED with 3 color (Red, Green, Orange)			
<b>Operating parameters</b>					
Operating temperature	-25 – 50 °C				
Relative humidity	0 – 95 %				
Operating Elevation	0 – 3000 m				
Storage temperature	-15 – 45 °C				
Storage relative humidity	0 – 95 %				
Storage altitude	0 – 15000 m				
Volume	max 85 dB				
Physical parameters					
Height	24mm				
Width	78,97mm				
Depth	117,23mm				
Weight	65g				
Color	RAL7035, RAL7012				







### **Compatible operating systems**

The list of accompanying programs (virtual serial port setup, communications software, etc. ...) Compatible Operating Systems:

- Microsoft Windows 98
- Microsoft Windows 2000
- Microsoft Windows NT
- Microsoft Windows XP
- Microsoft Windows Vista
- Microsoft Windows 7
- Microsoft Windows 8
- Microsoft Windows 8.1


Other operating systems to use (OS X, Linux) we recommend the USB HID device emulation (keyboard emulation).







# **Technical drawings**










# Wiring, connection

Proxer7 OEM (1)






PROCONTROL ELECTRONICS LTD www.procontrol.hu



41. oldal / 44



#### Proxer7 OEM (2)





PROCONTROL ELECTRONICS LTD www.procontrol.hu



42. oldal / 44



#### Proxer7-FF-232









# **Technical supports**

Should you have any problems or need assistance with you Procontrol Products, please feel free to contact our support department by any of the means below:

#### **Procontrol Electronics Ltd.**

www.procontrol.hu

6725 Szeged, Cserepes sor 9/b.

Tel: (62) 444-007

Fax: (62) 444-181

Email: info@procontrol.hu

#### Service:

Email: <a href="mailto:service@procontrol.hu">service@procontrol.hu</a>



PROCONTROL ELECTRONICS LTD www.procontrol.hu



44. oldal / 44